



### 161 DOOR TEMPLATE

FR2000

- 2 1/8" bore.
- Make a fast and accurate 2 1/8" bore and door latch prep with this template.
- Takes seconds to mark the door!



### DEADBOLT DOOR TEMPLATE

FR2001

- 1 1/2" bore.
- Make a fast and accurate 1 1/2" bore and door latch prep with this template.
- With our templates there is no wasted time.



### ASA DOOR TEMPLATE

FR2002

Make a fast and accurate 4 7/8" ASA cut-out on a door with this template.



### FLUSH BOLT DOOR TEMPLATE

FR2003

Make a fast and accurate 1" x 6 3/4" flush bolt cut-out on an inactive door with this template.



### 86 EDGE DOOR TEMPLATE

FR2004

Make a fast and accurate 8" mortise lock cut-out on a door with this template.

**HINGE DOOR TEMPLATE****FR2005**

Make fast and accurate hinge cut-outs on a door with this template.

**ASA FRAME TEMPLATE****FR2006**

Make fast and accurate ASA cut-outs on a frame with this template. Takes seconds to mark a frame!

**DEADBOLT FRAME TEMPLATE****FR2007**

Make fast and accurate deadbolt cut-outs on a frame with this template.

**FLUSH BOLT FRAME TEMPLATE****FR2008**

Make fast and accurate flush bolt cut-outs on a frame with this template.

**HINGE FRAME TEMPLATE****FR2009**

Make fast and accurate flush bolt cut-outs on a frame with this template.

Templates for 3 1/2", 4 1/2" and 5" hinge cut-outs, custom templates for both doors and frames are available.  
**CONTACT US FOR FURTHER INFORMATION**