


# How to Order

# FOR EXIT DEVICES:

N1500, N1550, N1650, N1700(F),  
N1750(F), N1800(F), N500, N550,  
N650, N700(F), N750(F)



\* For device functions, please refer to EXTERIOR TRIM (see page 12) and LEVER TRIM (see page 13).  
NOTE: DEVICE FUNCTION 1 is Exit Device Only, NO TRIM

\*\* Different devices and trim offer different finish options, please refer to your choice of device and trim for available finishes.